



- NOTES:
- A. VISIT GRACECONSTRUCTION.COM FOR THE MOST CURRENT DETAILS AND INSTALLATION VIDEO
 - B. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION
 - C. PRIME MASONRY CHIMNEY WITH PERMA-BARRIER® WB PRIMER AS NECESSARY
 - D. RIPCORD® HAS BEEN REMOVED ALONG ROOF AND CHIMNEY FOR EASE OF INSTALLATION
 - E. INSTALL GRACE UNDERLAYMENT IN ORDER AS SHOWN BY NUMBERS
 - F. APPLY A BEAD OF COMPATIBLE SEALANT ALONG THE TOP TERMINATION EDGE OF GRACE UNDERLAYMENT ON CHIMNEY
 - G. EXTEND GRACE UNDERLAYMENT FROM EAVE TO BELOW CHIMNEY AND FROM ABOVE CHIMNEY TO RIDGE
 - H. INSTALL GRACE UNDERLAYMENT TO FORM WATER-SHEDDING LAPS
 - I. REFER TO NRCA OR SMACNA FOR METAL COUNTERFLASHING AND ROOFING OPTIONS AT CHIMNEY
 - J. FOR WOODEN CHIMNEY, REFER TO DETAILS IWSDDET-105 AND IWSDDET-106

CHIMNEY

GRACE ICE & WATER SHIELD®

Drawings: IWSDDET-108
Scale: Not to scale
Effective Date: 05/16/2006
Supersedes: 01/27/2004