



NOTES:

1. VISIT GRACECONSTRUCTION.COM FOR THE MOST CURRENT DETAILS AND INSTALLATION VIDEO
2. REFER TO PRODUCT DATA SHEETS ON WEBSITE FOR FURTHER INFORMATION
3. THE DRIP EDGE IS INSTALLED OVER THE GRACE ROOF DETAIL MEMBRANE
4. LAYER OF UNDERLAYMENT IS INSTALLED OVER THE DRIP EDGE
5. INTEGRATE GRACE ROOF DETAIL MEMBRANE AND UNDERLAYMENT TO FORM WATER-SHEDDING LAPS
6. REPAIR ALL HOLES LEFT FROM REMOVAL OF TOE BOARDS, ROOF JACKS, ETC.