

- D. INSTALL VYCOR PLUS AND VYCOR enV TO FORM WATER-SHEDDING LAPS
- E. INSTALL VYCOR PLUS AROUND REMAINING DOOR UNIT PER DETAILS (VCRDET-100 TO 103, 111 AND 200)
- F. DETAIL ALSO RELEVANT FOR ALL VYCOR FLASHINGS
- G. REFER TO LOCAL BUILDING CODE REQUIREMENTS FOR WEATHER RESISTIVE BARRIER



## **EXTERIOR DOOR SILL CORNER**

**VYCOR® PLUS SELF-ADHERED FLASHING** 

**Drawing: VCRDET-201** 

Scale: Not to scale

Effective Date: 04/01/09

**Supersedes: 01/31/07**