



MECHANICALLY FASTEN AS NECESSARY IN CORNERS THROUGH VYCOR PLUS

WEATHER RESISTIVE BARRIER

TAPE

(ASSEMBLED WINDOW)

VYCOR PLUS

VYCOR PLUS

VYCOR PLUS

WEATHER RESISTIVE BARRIER

FOLD UP WEATHER RESISTIVE BARRIER AND TEMPORARILY SECURE

EXTERIOR SHEATHING

TRIM WEATHER RESISTIVE BARRIER 2" MINIMUM FROM ROUGH OPENING ALONG JAMBS AND SILL

SILL PLATE (SEE VCRDET-106 FOR OPTIONS)

VYCOR PLUS

VYCORNER™ OR CORNER PATCH RECOMMENDED (SEE VCRDET-507 OR VCRDET-504 FOR OPTIONS)

DO NOT FLASH OVER BOTTOM NAILING FLANGE

NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT DATA SHEETS
- B. RIPCORD® CAN BE REMOVED FROM VYCOR PLUS FOR EASE OF INSTALLATION
- C. REMOVE WEATHER RESISTIVE BARRIER FROM TOP OF WINDOW SILL PLATE
- D. INSTALL VYCOR PLUS IN ORDER AS SHOWN BY NUMBERS
- E. INSTALL VYCOR PLUS AND WEATHER RESISTIVE BARRIER TO FORM WATER-SHEDDING LAPS
- F. DETAIL ALSO RELEVANT FOR VYCOR V40 AND VYCOR BUTYL

HEAD FLASHING TIE-IN INSTRUCTIONS:

- 1. CUT, FOLD UP AND TEMPORARILY SECURE WEATHER RESISTIVE BARRIER ABOVE HEADER TO ALLOW FOR FLASHING INSTALLATION
- 2. INSTALL VYCOR PLUS HEAD FLASHING UNDER WEATHER RESISTIVE BARRIER ALONG HEADER
- 3. FOLD WEATHER RESISTIVE BARRIER BACK OVER HEAD FLASHING AND SEAL WITH TAPE AS SHOWN ABOVE



FLANGED WINDOW - OPTION 2
FLASHING INSTALLATION AFTER WEATHER RESISTIVE BARRIER
VYCOR® PLUS SELF-ADHERED FLASHING

Drawing: VCRDET-111

Scale: Not to scale

Effective Date: 01/31/07

Supersedes: 09/01/05