



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT INFORMATION SHEETS
- B. ALL EXPOSED (UNCOVERED) VYCOR ALONG MOST OUTER EDGE SHOULD BE TRIMMED FLUSH WITH JOIST TO PREVENT DAMAGE FROM UV
- C. VYCOR DOES NOT NEED TO BE TRIMMED IF COVERED WITH DECORATIVE TRIM, FASCIA OR OTHER APPROPRIATE MATERIAL