



OPTION A



OPTION B



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT DATA SHEETS
- B. RIPCORD® CAN BE REMOVED FROM VYCOR PLUS FOR EASE OF INSTALLATION AND FUTURE TIE-INS
- C. IF APPLICABLE, REMOVE WEATHER RESISTIVE BARRIER FROM TOP OF WINDOW SILL PLATE
- D. INSTALL SILL FLASHING AS SHOWN ABOVE
- E. INSTALL VYCOR PLUS AROUND REMAINING WINDOW UNIT PER GCP APPLIED TECHNOLOGIES WINDOW DETAILS (VCRDET-100 TO 111)
- F. CHECK LOCAL BUILDING CODES FOR WEATHER RESISTIVE BARRIER REQUIREMENTS AND INSTALL VYCOR PLUS WITH WEATHER RESISTIVE BARRIER TO FORM WATER-SHEDDING LAPS
- G. A BACK DAM CAN BE ACCOMPLISHED USING A WOODEN FURRING STRIP, AS ILLUSTRATED ABOVE, OR BY FOLDING THE VYCOR PLUS ADHESIVE LAYER ONTO ITSELF
- H. **OPTION-C:** INSTALL WOODEN FURRING STRIP ON TOP OF WOODEN SIDING PRIOR TO VYCOR PLUS
- I. FOR SILL PAN DEPTHS GREATER THAN 6 INCHES, A SLOPED SILL IS REQUIRED IN ACCORDANCE WITH ASTM E 2112
- J. DETAIL ALSO RELEVANT FOR VYCOR V40 AND VYCOR BUTYL